



X263 User Guide

User Guide

INTRODUCTION

Thank you for purchasing this Micromax mobile phone. To obtain the best performance of your phone, please read this user manual carefully.

User Guide

Table of Contents

1	.Introduction	2	3	.Calling.....	9
1.1	Phone and Accessories	2	3.1	Mute' a Call	9
1.2	Your Phone.....	2	3.2	DTMF (Dual Tone MultiFrequency)	9
1.3	About your Phone.....	3	3.3	Call Waiting	9
1.4	About the SIM Card	3	3.4	Call Divert.....	9
1.5	Switch ON and OFF.....	4	3.5	Call Barring	10
2	.Phonebook.....	5	3.6	Conference Call.....	10
2.1	View a contact.....	5	4	.Call Logs	11
2.2	Call a Contact.....	5	4.1	All Calls	11
2.3	Send a Text Message.....	5	5	.Messages.....	12
2.4	Send a Multimedia Message	5	5.1	Messaging	12
2.5	Edit a Contact	6	6	.Profile Setup.....	17
2.6	Delete a Contact.....	6	7	.Multimedia.....	18
2.7	Multi Operation	6	7.1	Camera	18
2.8	Copy a Contact.....	6	7.2	Image Viewer	18
2.9	Move a Contact	6	7.3	Video Recorder	19
2.10	Add to Blacklist	7	7.4	Video Player	20
2.11	Send vCard to a Contact.....	7	7.5	Audio Player	20
2.12	Export vCard	7	7.6	Sound Recorder	21
2.13	vCard Backup	7	7.7	FM Radio.....	21
2.14	Phonebook Settings.....	7	7.8	Fun & Games	23

User Guide

8	.Settings.....	24
8.1	Customized Phone & Call Settings	24
8.2	Security Settings	25
9	.Organizer.....	27
10	.File Manager.....	28
11	.Services.....	29
11.1	WAP Browser	29
11.2	Data Account	29
11.3	Bluetooth	30
	Health and Safety Precautions.....	31
	Taking Care of Your Device.....	33

1.Introduction

1.1 Phone and Accessories

Open the packing box of the phone and check that you have the following:

User Guide

- Transreceiver
- Standard Charger
- Standard Battery
- Handsfree Kit
- User Guide
- Service Guide
- Warranty Card

1.2 Your Phone



User Guide

1.3 About your Phone

Your X263 supports dual GSM cards. The phone comes with a wireless FM Radio and a Flashlight at the top of the phone. Long press the “OK” key to turn the Flashlight on/off. You have the option of writing messages in both Hindi and English languages.

1.4 About the SIM Card

Please store the cards out of childrens’ reach. The SIM card and the contacts are vulnerable to damage due to scratching or bending. Therefore, be careful when using, inserting or removing the SIM cards.

Be sure to switch off the phone before you insert or remove the battery or the card, otherwise, the phone may get damaged.

Tips:

Please charge the battery before you use the newly purchased phone. We suggest you to charge the battery for 4 hours continuously for the first time.

Charging when the phone is in the ON mode will not influence the normal dialing and answering operations, but as this consumes power, thus the time of charging will increase.

We suggest you to recharge the battery when the power is used up so as to prolong the life of the battery.

User Guide

1.5 Switch ON and OFF

To switch ON: Long press the **End key** when the phone is in the OFF mode.

If the phone lock has been activated, you need to enter the 4-digit password to unlock it. (The preset unlock code is 0000.)

If the SIM card has been inserted in the phone, and the related PIN code protection is activated, you need to enter the 4-8 digit passwords to unlock.

Warning: If you enter the wrong PIN codes three times in a row, the SIM card will be locked and you need to enter the PUK code to unlock. Both the PIN code and PUK code are provided by the network operator.

To switch OFF: In the standby mode, long press **End key**.

2.Phonebook

You can store names and phone numbers in the memory of the phone or SIM card.

Menu > Phonebook

2.1 View a contact

Menu > Phonebook > Options> View

View the details of the contact.

2.2 Call a Contact

Menu > Phonebook > Options> Call

Allows you to make a call on the contact you are viewing.

2.3 Send a Text Message

Menu > Phonebook > Options> Send text message

Allows you to send a text message to the contact

2.4 Send a Multimedia Message

Menu > Phonebook > Options> Send multimedia message

Allows you to send a multimedia message to the contact.

User Guide

2.5 Edit a Contact

Menu > Phonebook > Options> Edit

To edit the contact.

2.6 Delete a Contact

Menu>Phonebook> Options> Delete

In the Contacts list, select the entry you want to delete.

2.7 Multi Operation

Menu > Phonebook > Options>Multi operation

Allows you to mark single or multiple contacts together to perform functions such as- send text message, delete, copy.

2.8 Copy a Contact

Menu>Phonebook> Options> Copy

You can copy all entries stored in the SIM card to the phone memory and vice-versa

2.9 Move a Contact

Menu>Phonebook> Options> Move

Move the record from current storage to the other storage.

User Guide

2.10 Add to Blacklist

Menu>Phonebook> Options> Add to Blacklist

Allows you to add the contact number in the Blacklist folder. By doing so, the number listed under the blacklist folder will be barred from making calls on your number.

2.11 Send vCard to a Contact

Menu>Phonebook> Options>Send vCard

Allows you to send a contact as a business card to other numbers.

2.12 Export vCard

Menu>Phonebook>options>Vcard Export

Allows you to export a single vcard.

2.13 vCard Backup

Menu > Phonebook > Options> Export and Import

Allows you to take a backup of the vCard.

2.14 Phonebook Settings

Menu > Phonebook> Options> Phonebook settings

User Guide

Allows you to do settings for the phonebook.

Note: The phonebook displays 4 tabs on the top of the screen which are:

- **All list:** That allows you to view contacts stored both in the phone and memory card
- **Phone list:** That allows you to view contacts stored only in the phone memory
- **SIM list:** That allows you to view contacts in either the SIM A or SIM B memory
- **Caller groups:** Allows you to add contacts under specified categories.

3. Calling

3.1 Mute' a Call

During a call, you can prevent the other party from hearing you:

While on call > Mute

3.2 DTMF (Dual Tone MultiFrequency)

During a call, you can select to turn ON or turn OFF the DTMF tone. When the DTMF tone is turned off, the digits entered will not be regarded as a DTMF signal response.

3.3 Call Waiting

Menu > Settings > Call settings > SIM A/B call settings>Call waiting

This function allows you to put the current call on hold and then answer a second one.

If, during a call, a new call comes in, you will hear a special alert sound and the screen will display the number of the new incoming call, which indicates that a third-party call is coming in and waiting for answer.

3.4 Call Divert

Menu > Settings > Call settings > SIM A/B call settings>Call divert

With the Call Divert function (needs network support), you may divert incoming calls to another mobile phone

User Guide

or a direct line telephone, but not to any extensions of a fixed telephone.

The function needs the support of your subscribed network. In some circles, you can use the function only after you apply to the local network operator.

3.5 Call Barring

Menu > Settings > Call settings > SIM A/B call settings > Call barring

This is a GSM network service and can restrict outgoing and incoming calls selectively. If you need to change the settings of Restrict Calls, please contact your network operator to obtain the password for opening this service.

3.6 Conference Call

The phone supports three-party Calling. A Three-party calling, also called a multi-party call or a conference call, is a service based on call waiting. It is applicable to dual standby with GSM network.

The function needs the support from the local network. In some circles, you can use the function only after you apply with the local network operator.

4.Call Logs

4.1 All Calls

When on the standby interface, you can press the call key to enter the call logs.

You may view all your call log entries under **All Calls**.

- **View:** View the desired entry
- **Call:** Call the desired entry
- **Send text message:** To write SMS to send to the number.
- **Send multimedia message:** To write MMS to send to the number.
- **Save to Phonebook:** To save the number to the Phonebook
- **Add to Blacklist:** To add the number to the blacklist.
- **Edit before call:** You can edit the number before call
- **Delete:** To delete the entry.

5.Messages

5.1 Messaging

If you want to write an SMS:

Menu > Messaging > Write message>Text message

Write the content of the Message, **options>**

- **Send to:** Send the message directly.
- **Input method:** To choose a text input method.
- **Insert template:** You can insert template into the SMS.
- **Advanced:** You can insert number/contact/bookmark into the SMS.
- **Save to drafts:** Save the message into the draft box.

If you want to write a Multimedia message:

Menu > Messaging > Write message>Multimedia message

Write the content of the Message, **options>**

- **Send to:** Send the message directly.
- **Input method:** To choose a text input method.
- **Add picture:** Insert a picture into the MMS.

User Guide

- **Add sound:** Insert a sound file into the MMS.
- **Add video:** Insert a video file into the MMS.
- **Add subject:** Add a subject.
- **Preview MMS:** You can preview the MMS.

Slide options: You can add slide behind/before and set the slide time.

- **Advanced:** You can have the following options,
 - Insert text template
 - Insert attachment
 - Insert bookmark

Save to drafts: Save the MMS into the draft folder.

If you want to write a Flash message:

Menu > Messaging > Flash message

Write the content of the Flash message, options>

- **Send to:** Send the message directly.
- **Input method:** To choose a text input method.
- **Insert template:** You can insert template into the SMS.
- **Advanced:** You can insert number/contact/bookmark into the SMS.

User Guide

- **Save to drafts:** Save the message into the draft box.

Menu > Messaging> Inbox

To read a message, highlight the entry and press **OK**.

When reading a message, You can select **options>**

- **Reply by SMS:** Allows you to reply to the message by SMS.
- **Reply by MMS:** Allows you to reply to the message by MMS.
- **Call sender:** Call the message sender.
- **Forward:** To forward the message to othercontact(s).
- **Delete:** Delete the selected message.
- **Advanced:** You can perform the following operations
 - Use number
 - Use USSD

Menu > Messaging> Drafts

This allows you to read the Messages saved during editing.

- **View:** Allows you to view the messages in the drafts box.
- **Send:** Send the message.
- **Edit:** Edit the selected message.

User Guide

- **Delete:** Allows you to delete the selected message.
- **Delete all:** Allows you to delete all the messages saved in the drafts box.
- **Sort by:** Sort the messages by desired method.

Menu > Messaging > Outbox

Read messages sent failed.

When reading an SMS, you can select **Options >**

- **Resend:** Resend the messages to the recipient again.
- **Edit:** Allows you to edit the message.
- **Delete:** Delete the selected Message.
- **Advanced:** You can perform the following operations
 - Use number
 - Use USSD

Menu > Messaging> Sent messages

View all the messages sent to various recipients under this folder.

Menu > Messaging > Delete folder

Delete message folders: Inbox, outbox, drafts, sent messages or delete all folders.

Menu > Messaging > Broadcast messages

Broadcast message is an information service to all GSM users in a specific location sent by the network

User Guide

operator, such as the weather forecast, transportation conditions and so on.

- **Receive mode:** Choose whether to enable or disable cell broadcast.
- **Read message:** Read the received cell broadcast.
- **Languages:** Choose the display language of cell broadcast.
- **Channel settings:** Set the channel of cell broadcast.

Menu > Messaging> Templates

Enter into preset message templates and view or use them.

Menu>Messaging> Message settings

You can set parameters for Text message/Multimedia message/Service message.

User Guide

6.Profile Setup

Functions	Description
Activate the profile mode	Menu > Settings> User profiles>Desired profile>options >Active
Activate 'silent mode' in idle condition	Press “#”key to change the general mode to silent mode, Press “#” again to go to General mode again.
Set the ringtone for incoming calls	Menu >Settings>User profiles >Options> Customize >SIM A/B incoming call
Set the tone for messages	Menu> Settings> User profiles>Options>Customize>>SIMA/B message Tones
Set the tone for MMS	Menu> Settings>User profiles>Options>Customize> MMS tones
Active the system alert	Menu> Settings>User profiles>Options> Customize > System alert
Set the tone for “keypad tones”	Menu> Settings>User profiles>Options>Customize>Keypad tones
Adjust the volume of Ring Tone /message tone/ Key Tone	Menu > Settings> User profiles>Options > Customize > Ringtone volume/Message volume/Keytone volume
Set Alert Type of ringing	Menu > Settings> User profiles > Options> Customize>Alert type
Set the ringtone type	Menu > Settings> User profiles > Options > Customize> Ring type

7.Multimedia

7.1 Camera

Menu > Multimedia > Camera:

The built-in camera allows you to take photos and adjust the camera settings. The options menu contains the following choices:

- **Photos:** View the saved photos.
- **Camera settings:** Set relevant parameters for the camera.
- **Image settings:** Set the size and quality of photos.
- **White balance:** you can set the white balance of the camera.
- **Scene mode:** Set the scene mode of photo.
- **Effect settings:** Set different effects to display photos.
- **Storage:** Set the storage location of the photos.
- **Restore default:** Restore camera settings to default.

7.2 Image Viewer

Menu > Multimedia > Image viewer

User Guide

On the Image viewer list screen, select **Options>**

- **View:** To view the picture.
- **Image information:** To view the image information.
- **Browse style:** Set browse style of photos.
- **Send:** Send present image through MMS or Bluetooth.
- **Use As:** You can use the images as wallpaper, screen saver or caller picture.
- **Rename:** Rename the highlighted file.
- **Delete:** Delete the highlighted file.
- **Sort by:** Sort the images by desired method.
- **Delete all files:** Delete all the files from the list.
- **Storage:** Set the storage location for the photos.

7.3 Video Recorder

Menu > Multimedia > Video recorder

Press the **Center Key** to record.

Before recording, you can set the following as needed. Select **Options >**

- **Video Recorder settings:** Set relevant parameters for shooting videos.

User Guide

- **Video settings:** Set relevant parameters for the video.
- **White balance:** You can set the white balance of the video recordings
- **Effect settings:** Set the different effects to display videos.
- **Storage:** Set the storage location for the video files.
- **Restore default:** Restore video setting to default.

7.4 Video Player

Menu > Multimedia > Video player

The Video Player plays all your video files stored in the phone (Phone Memory or on the Memory Card). The video player gives you the following options:

- **Play:** To start playing the video file.
- **Refresh list:** You can refresh the list of videos.
- **Settings:** Set relevant parameters for the video player.

7.5 Audio Player

Menu > Multimedia > Music

The Micromax X263 comes with an inbuilt audio player that plays all your favorite songs stored in the phone memory or T-Flash memory card. It gives you a host of options to make your listening experience interesting.

- **Play:** To start playing the audio file.

User Guide

- **Details:** To show the details of the selected song.
- **Add:** Add songs to the playlist.
- **Remove:** Remove the selected song from the playlist.
- **Remove all:** Remove all the songs from the playlist.
- **Settings:** Set some relevant parameters for the audio player.

7.6 Sound Recorder

Menu > Multimedia > Sound recorder

On the Sound Recorder list screen, you can select:

- **New record:** begin recording. The recordings will be saved in the **Audio** folder.
- **List:** List all the recorded file.
- **Settings:** Set some relevant parameters for the sound recorder.

7.7 FM Radio

Menu > Multimedia>FM radio

Note: Play your favourite radio stations without having to connect to the handsfree. Enjoy wireless radio through the antenna.

Options > Channel list

User Guide

List all the currently tuned channels. You can enter channel list, edit it and display the searched channel list.

Options > Manual tuning

Input the desired broadcasting channel manually.

Options > Auto Search

Automatically search FM and setup.

Options > Settings

Select the Radio background type and cell phone speaker, recording format, storage device.

Options> Record

To record the current program being played on the radio.

Options > Append

To append the recording to an existing recording. In this case, the recordings will be combined as a single file.

Options>File list

To view the list of recorded files

To Increase/Decrease the volume:

To increase the volume, press the * key and to decrease the volume press the # key.

To switch between channels:

Press the number keys on your keypad in accordance with the channel list.

7.8 Fun & Games

Menu >Applications> Fun & Games

Enjoy playing the preloaded games in your phone & cross various levels in it to achieve a high score, thereafter have your friends try and break your record!

User Guide

8.Settings

8.1 Customized Phone & Call Settings

Functions	Description
Set time and date	Menu > Settings > Phone settings> Time and date
Schedule power on/off	Menu > Settings > Phone settings > Schedule power On/Off To disable and enable status; to activate/deactivate, switch on/off, and time in turn.
Select display language	Menu > Settings > Phone settings > Language
Set Display Settings	Menu > Settings > Phone settings > Display setup Wallpaper/Screen saver/LCD backlight/Show date and time/Show owner number
Preferred input method	Menu>settings>phone settings> Preferred input methods
Specify the Dedicated key	Menu > Settings > Phone settings> Dedicated key By default: ▪ Up > Music ▪ Down > Write message ▪ Left > Alarm ▪ Right > Calendar Menu>Settings>Phone settings>Auto update time

User Guide

	Menu>Settings>Phone settings>Shortcuts
Set Call waiting	Menu > Settings > Call settings>SIM A/B call settings>Call waiting
Set Call divert	Menu > Settings > Calling settings>SIM A/B call settings > Call divert Tip: You can select Cancel all divert to cancel all the divert settings.
Set Call barring	Menu > Settings > Call settings>SIM A/B call settings > Call barring
Line switching	Menu> Settings> Calling settings > SIM A/B call settings> Line switching
Select network	Menu > Settings >Network settings Select preferred Network: The phone will search and display the list of known networks for you to select the desired one, after which, the phone will try to latch on to the selected network.
Set reception mode	Menu>Settings>Reception Mode: Dual SIM active/Only SIM A/B active/Flight mode
Restore factory settings	Menu>settings>Restore factory settings

8.2 Security Settings

Functions	Description
Phone lock	Menu > Settings> Security settings> Phone lock The preset password is 0000
Change password	Menu>Settings> Security settings> Phone lock > Change password
SIM lock	Menu>settings> Security settings> SIMA/B security > PIN lock SIM lock protects the illegal usage of the SIM card by unauthorized users.
Change PIN	Menu>settings>Security settings> SIM A/B security> change PIN
Change PIN2	Menu>settings> Security settings> SIM A/B security> change PIN2

User Guide

Auto keypad lock	Menu > Settings > Security settings > Auto keypad lock Note: Press the Left Soft Key and * key to unlock the phone.
------------------	--

User Guide

9.Organizer

Functions	Description
View the calendar	Menu > Organizer > Calendar
Tasks	Menu > Organizer > Tasks
Set the alarm	Menu > Organizer > Alarm
World clock	Menu > Organizer > World clock
Calculator	Menu> Applications > Calculator
Stopwatch	Menu> Applications > Stopwatch
Unit converter	Menu> Applications> Unit converter
Currency converter	Menu> Applications> Currency converter
Health	Menu> Applications> Health
Flashlight	Menu> Applications> Flashlight
Text reader	Menu> Applications> Text reader

User Guide

10.File Manager

When a USB cable is connected, you can use the phone as a USB mass storage device.

Functions	Description
View folders	Menu > File manager> Options > Open
Rename	Menu>File manager >Options>Rename
Format	Menu>File manager>Options>Format
Remove	Menu > File manager > Options> Remove
Details	Menu > File manager > Options > Details

11.Services

11.1 WAP Browser

Menu > Connectivity>WAP

You need to make the relevant settings in WAP Setup before you use the WAP browser to surf the web.

When the WAP browser is activated, if a homepage is set in WAP Setup, the phone will link the website indicated by the homepage; otherwise, you may enter a website and the phone will connect to it.

When surfing the web, select **Options >**

- **Homepage:** Start a connection to the selected URL set.
- **Bookmarks:** Access or edit a bookmark.
- **Input address:** Enter the address.
- **Recent pages:** Browse a saved URL.
- **Settings:** Set parameters of WAP browser

11.2 Data Account

Menu>Connectivity>Data account

Support GSM and GPRS data account.

11.3 Bluetooth

- **Power:** On/Off
- **Visibility:** On/Off
- **My device:** Display device model when connected.
- **Inquiry audio device:** Search for Bluetooth audio devices.
- **Device Name:** Change the displayed name of this phone device.
- **Advanced:** You can set some relevant parameters for Bluetooth.

User Guide

Health and Safety Precautions

Please read these simple guidelines. Not following them may be dangerous or illegal.

SAR Compliance

- Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines.
- SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The SAR value of the phone may depend on factors such as proximity to the network tower, use of accessories.
- The highest SAR value of the device is 0.995 W/kg (head) and 0.972 W/kg (body) averaged over 1 gm of human tissue.

SAR Recommendations

- Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.
- Make sure the cell phone has a low SAR.
- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to

User Guide

children, adolescents and pregnant women

- Prefer to use your cell phone when the signal quality is good.
- People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.
- Maintain a preferable distance of 15 mm from the device.

Safe Driving

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
- Please do not put the phone onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

During Flight

- Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

In Hospitals

- Your Phone's radio waves may interfere with the functioning of inadequately shielded medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations posted instruct you to do so.
- To avoid potential interference with implanted medical devices such as a pacemaker or cardioverter defibrillator:

User Guide

- Always keep your phone at least 15.3 centimeters (6 inches) from the medical device.
- Do not carry the wireless device in a breast pocket.
- Turn off the phone if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.
- If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Unsafe Areas

- Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.
-

Taking Care of Your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery without turning on the device, wipe it with a dry cloth and take it the service center.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.

User Guide

- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing this phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time.

Battery Recommendations:

- Please put the battery in a cool and well-ventilated place out of direct sunlight. We recommend you to charge the battery at room temperature range.
- Batteries have life cycles. If the time that the battery powers equipment becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.
- Use manufacturer approved batteries, chargers, accessories and supplies. Micromax will not be held responsible for user's safety when using unapproved accessories or supplies.
- Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.

User Guide

Recycle Your Phone



The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed off or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling. of such hazardous waste.

Collection and proper recovery of your electronic waste equipments at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site: www.micromaxinfo.com/weee.php.

Disclaimers

- The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned

User Guide

herein may be trademarks or trade names of their respective owners.

- Micromax keeps the right to make modifications to any of the content in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed in the mobile phone. In such a case, the latter shall govern.

Copyrights

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Micromax is strictly prohibited.